

From times before the ancient Egyptians Incense burners have been used to scent palaces and temples. The sensuous rise of the curling smoke from sandalwood, bergamot or ambergris permeated everything. So it is with Evan's & Brown's Incense®, a texture to transfer walls into the realm of the senses.

| | US UNITS | METRIC UNITS |
|--------------------------|--|--|
| Total Weight | 28.0 oz PLY 18.67 oz PSY | 868 g PLM 633 g PSM |
| Roll Width | 53/55 in. | 134/139 cm |
| Gauge | 28 Mils | 0.71 mm |
| Fabric | Non-Woven | |
| Tensile (Minimum) | 50 x 50 lb _f | 222 x 222 N |
| Tear (Minimum) | 25 x 25 | |
| WA Spec | WA-W-101, Type II | |
| Fire Testing | NFPA 101® Life Safety Code® NFPA255 (UL723, CAN S102M) Tunnel Test ¹ Class A Rating NFPA 286 Corner Burn Test ² Meets requirements for Flame Spread, Smoke Developed and Flashover | |
| Repeat | Vertical | N/A |
| | Horizontal | 1.5 in. 3.8 cm |
| | Nominal Pattern Width | 53 in. 134 cm |
| | Match Information | Straight Match, Reverse Hang Slit outside of arrows on both sides |
| | 1 When applied to GRC Board with A-848-B adhesive | 2 When applied to 5/8" Type-X gypsum board with A-848-B adhesive |

Available in 15 Colorways

- *P128-50 Ambergris
- *P128-62 Ginger
- *P128-67 Bergamot
- *P128-89 Grasse
- *P128-78 Blue Camphor
- *P128-38 Myrrh
- *P128-46 Brazier
- P128-76 Provance
- *P128-31 Candelabra
- *P128-43 Sandalwood
- *P128-84 Chimera
- *P128-23 Taffeta
- *P128-65 Civet
- *P128-15 Vanilla
- *P128-06 Flora

***These decorative metallic wallcoverings should only be cleaned with mild ingredients such as soap, detergent and water. Stronger, more alkaline household cleaners have the potential to damage the surface of the wallcovering along with excessive scrubbing.**