

KOROSEAL WALLCOVERINGS

**APPLICATION**

Recommended for lining over sand finish plaster, cement block, V-grooved paneling, and other problem walls to provide a smooth base on which to apply other wallcoverings.

This material is intended as a lining for bridging cracks or other cavities, but it will not hide any wall imperfections, such as protrusions or misalignments of cement block.

**WALL PREPARATION**

Acceptable hanging surfaces must be clean, thoroughly dry and structurally intact. All loose paint and other wallcoverings must be removed. Paneled walls should be washed to remove oils, wax or polish. Adhesion may be enhanced by scoring surface with coarse sandpaper and priming with diluted adhesive. Concrete block and similar highly porous surfaces should also be sanded as smooth as possible first, and then sized with diluted adhesive. Let dry for at least 2 hours.

Use only a lead pencil for marking walls and back of lining material. Do not use ballpoint pen or marking pen. Any mildew must be removed from walls and surfaces treated to inhibit further mildew growth. Do not install unless a temperature of at least 55°F is maintained in both areas of installation and storage.

**ADHESIVE**

Koroseal Wallcoverings A-848-B premixed vinyl wallcovering adhesive is recommended for use in installing Koroliner™ lining material. When used as a primer, it may be diluted with up to 1 quart of clean water per gallon of adhesive.

**PASTING AND HANGING**

Paste only one strip at a time.

Brush or roll Koroseal Wallcoverings A-848-B pre-mixed vinyl adhesive thoroughly over the back, particularly at the edges. To carry material to the wall, fold wet side to wet side, but avoid creasing material. Depending on viscosity, a slight amount of moisture may come through wall liner bookfolding. This is not detrimental. Align first strip to plumb line. Smooth any overlap onto ceiling and baseboard.

Smooth covering to wall with a smoothing brush. Be sure to remove all air pockets. Butt or double-cut all seams. **DO NOT OVERLAP.** Setting seams with a seam roller will help prevent them from opening. Use scissors or single edge razor blade to trim excess at baseboard, ceiling and around windows.

Allow 24 hours to dry before hanging a second wallcovering.